30cm 2 Burner S.S Gas Hob
COOKTOP

PRODUCT CODE: **ECT30GX**

eurocooking

3 YEARS
Warranty

INSTALLATION DIAGRAM

FEATURES:

+ Stainless steel cooktop
+ 2 gas burners
+ Front knob controls
+ One piece hob for ideal cleaning
+ Automatic ignition

+ Cast iron pan supports
+ Flame failure safety device
+ Natural gas or LPG (jets included)

IDEAL CLEANING
Cook top surface all in a "one piece hob setting" which makes cleaning the cooktop a simple, non-time consuming activity.

ONE TOUCH ELECTRONIC IGNITION
This gas cooktop uses a one touch electronic ignition system. Simply push down the knob and turn and the flame will ignite automatically.

CAST IRON TRIVETS
Non-slip, cast iron trivets are standard with this cooktop and removable for easy cleaning.

FLAME FAILURE SAFETY DEVICE
The flame failure device is a safety mechanism which ensures the gas is automatically turned off in the case of the flame extinguishing.

SPECIFICATIONS:

|	
Electrical Requirements	Cooktop is supplied with 10 amp plug & cord.
Gas Rated Pressure:	
- LPG	2.75 kPa
- Natural	1.00 kPa
Gas Burners:	
- Rapid Gas Burner (Rear)	10.8 MJ/h
- Auxiliary Burner (Front)	3.60 MJ/h
Weight	8.5 kg net / 10.5 kg gross
Product Dimensions	300mm x 520mm x 100mm
Barcode	9347726024820

CLEANING AND MAINTENANCE

+ Cleaning operations must only be carried out when the appliance is completely cool.
+ Clean the appliance regularly, preferably after each use
+ Abrasive cleaners or sharp objects will damage the appliance surface; you should clean it using water and a little washing up liquid

SAFETY INFORMATION

+ Do not use this appliance if it comes in contact with water. Do not operate this appliance with wet hands
+ The heating and cooking surfaces of the appliances become hot when in use, take all due precautions.
+ Unstable pans should not be used on the appliances as they can cause an accident by tipping or spillage.
+ Never leave the appliance unnattended when cooking.
+ Please refer to the manual for more information