# 60cm Ceran Electric Cooktop COOKTOP

PRODUCT CODE: ECT60CR



# **FEATURES:**

- Smooth Ceran glass electric cooktop
- 4 heat elements
- Front sensor touch control operation
- Residual heat indicator

- 9 power stage settings
- Digital timer
- Square edge design
- Child Lock Safety

# RESIDUAL HEAT INDICATOR

To ensure that you know which electric hotplate is in use, this cooktop is equipped with a heating level indicator. After cooking, there will be some residual heat remaining & symbols will display.

# 9 POWER SETTINGS

SPECIFICATIONS:

Voltage

Frequency

**Total Rated Load:** 

**Heating Elements:** 

- Front Left Zone

- Rear Left Zone

- Rear Right Zone

- Front Right Zone

**Product Dimensions** 

Weight

**Electrical Requirements** 

9 levels of power settings to ensure maximum heat when needed & also low heat for slow cooking.

# 4 HEATING ELEMENTS

This ceramic cooktop is fitted with 4 elements to ensure they will provide different cooking zones and power settings to match with your cooking requirement.

# SMOOTH CERAN GLASS COOKTOP

27 amp dedicated circuit from cooktop to main switchboard

220V-240V 50Hz-60Hz

6500W

1800W

1200W

2300W


1200W

10.7kg (Gross) 9.0kg (Net)

**W**580mm x **D**510mm

A high-grade ceran glass is used for this cooktop to ensure easy cleaning of the smooth ceran surface

# INSTALLATION DIAGRAM



# eurocooking



# CLEANING AND MAINTENANCE

- Cleaning operations must only be carried out when the appliance is completely cool.
- Clean the appliance regularly, preferably after each use
- Abrasive cleaners or sharp objects will damage the appliance surface; you should clean it using water and a little washing up

# SAFETY INFORMATION

- The heating and cooking surfaces of the appliances become hot when in use, take all due precautions.
- Unstable pans should not be used on the appliances as they can cause an accident by tipping or spillage.
- Never leave the appliance unnattended when
- Please refer to the manual for more information