

34L Touch Control Convection MICROWAVE

PRODUCT CODE: **EMW34TBK**



FEATURES:

- + 34L Stainless Steel cavity
- + Touch control
- + White LCD display
- + 5 power levels & 4 combi
- + All black finish
- + 10 Auto menu
- + 95min Kitchen timer
- + Speedy cooking + multi-stage cooking
- + Child safety lock

TIMER

Use to set microwave cooking time. Allows you to set up to 95 minutes.

DEFROST BY TIME

Use to set microwave defrost time. This function will allow you to set a maximum of up to 95 minutes.

DEFROST BY WEIGHT

Defrost food according to weight from 100g to 2kg.

MULTI-STAGE COOKING

This feature allows you to set multiple stages of cooking for example, the defrost function followed by microwave function.

ELECTRIC REQUIREMENTS

This microwave is fitted with a cord and 10 amp plug.

POWER CONSUMPTION

Rated input power (microwave): 1550w
Rated output power (microwave): 1000w
Convection Input: 2300w
Rated Voltage: 220-240V

WEIGHT:

24.5kg (Gross) / 21.5kg (Net)

OVEN CAPACITY:

34 Litres

BARCODE:

9347726029054



eurocooking



Warranty

PRODUCT DIMENSIONS

595mm x 468mm x 388mm

CLEANING & MAINTENANCE

Easy clean interior. Clean stainless steel using only recommended stainless steel cleaning products. Abrasives, corrosive detergents, bleaches or acids not required for cleaning the microwave oven.

Clean the cavity of the oven after using with a slightly damp cloth.

The door frame, seal and neighbouring parts must be cleaned carefully with a damp cloth when they are dirty.

Do not use harsh abrasive cleaners or sharp metal scrapers to clean the oven door glass since they can scratch the surface, which may result in shattering of the glass.

INSTALLATION

Please refer to the product manual for full installation instructions.

Product must be installed by a qualified technician.

PRODUCT DIMENSIONS

